






POK Air Spring

AIR SPRINGS

CABIN

AS02-0020	For <u>VOLVO</u>	CABIN FRONT
	Model: F 10 - F12 - F16 OEM NO. 1586068 1622087	

AS02-0021	For <u>SCANIA</u>	CABIN FRONT/REAR(without Shock Absorber)
	Model: 4 SERIES (94/114/144) OEM NO. 1302684 1539260 1381919 1397395 1502468	**longer


AS02-0022	For <u>SCANIA</u>	CABIN REAR
	Model: OEM NO. 1476415	





POK Air Spring

AIR SPRINGS

CABIN

	AS02-0023	For <u>ISUZU</u>	CABIN	
			FRONT	REAR: AS02-0017
<p>Model: GIGA EXZ 360HP EXR82 6WA1T (360PS) 35T 97'~</p> <p>OEM NO. 1-52110142-0 1-52110142-1</p>				

	AS02-0024	For <u>NISSAN</u>	CABIN	
			FRONT	REAR: AS02-0025
<p>Model: GE13</p> <p>OEM NO. 95148-00Z14</p>				


	AS02-0025	For <u>NISSAN</u>	CABIN	
			REAR	FRONT: AS02-0024
<p>Model: GE 13</p> <p>OEM NO. 95246-00Z16</p>				





POK Air Spring

AIR SPRINGS

CABIN

AS02-0026	For <u>NISSAN</u>	CABIN FRONT	REAR: AS02-0027
	<p>Model: GH11 (410D)</p> <p>OEM NO. 95148-00Z16</p>		

AS02-0027	For <u>NISSAN</u>	CABIN REAR	FRONT: AS02-0026
	<p>Model: GH11 (410P)</p> <p>OEM NO. 95246-00Z17</p>		


AS02-0028	For <u>SCANIA</u>	CABIN REAR	
	<p>Model: 3 SERIES R series</p> <p>OEM NO. 1326748 1424231</p>		





POK Air Spring

AIR SPRINGS

CABIN

AS02-0029	For SCANIA	CABIN REAR
	Model: 4 SERIES OEM NO. 1498306 1444016	

AS02-0030	For FREIGHTLINER	CABIN REAR
	Model: OEM NO. GYR1S6031	


AS02-0032	For HYUNDAI	CABIN REAR
	HD310/HD320/HD370/HD380 04EM (2010~) Model: New Power Truck (2004~)Asia OEM NO. 64207-7E010	



POK Air Spring

AIR SPRINGS

CABIN

AS02-0033	For <u>HYUNDAI</u>	CABIN REAR
	<p>Model:</p> <p>OEM NO. 64207-7A001</p>	

	<p>Model:</p> <p>OEM NO.</p>	


	<p>Model:</p> <p>OEM NO.</p>	





POK Air Spring

AIR SPRINGS

SEAT

AS04-0001	For SCANIA	SEAT
	Model: 340HP ISRI	NOTE: TUBE 12 cm
	OEM NO. 1440529 1448573 SC112 113 114	

AS04-0025		SEAT
	Model:	
	OEM NO.	


AS04-0004	For FUSO	SEAT
	Model: F350	
	OEM NO. MC928557K	





POK Air Spring

AIR SPRINGS

PASSENGER CAR

AS10-0001	For <u>BMW</u>	PASSENGER CAR. REAR(L / R)
	Model: X5 E53 OEM NO. BB2948760 37121095579	

AS10-0002	For <u>BMW 5 series</u>	PASSENGER CAR. REAR
	Model: F07/F11 2009 ~ 2013 OEM NO. 6781843-06 11151110590102 F3075139010-0 R307513707A	


AS10-0003	For <u>BMW</u>	PASSENGER CAR.
	Model: E70/E71/F15 F16/F07/F11 OEM NO. 37126795013 F304225025	



POK Air Spring

AIR SPRINGS

PASSENGER CAR

AS10-0005	For <u>M-Benz</u>	PASSENGER CAR. REAR
	<p>Model: GL-Class: W164 / W166 ML-Class: W164 / W166</p> <p>OEM NO. F304234825 166 320 0325</p>	

	<p>Model:</p> <p>OEM NO.</p>	

	<p>Model:</p> <p>OEM NO.</p>	



POK Air Spring

AIR SPRINGS

New Products

	Model: OEM NO.
--	-------------------------------------

	Model: OEM NO.
--	-------------------------------------

	Model: OEM NO.
--	-------------------------------------



POK Air Spring

AIR SPRINGS

New Products

	<p>Model:</p> <p>OEM NO.</p>
--	--

	<p>Model:</p> <p>OEM NO.</p>
--	--

	<p>Model:</p> <p>OEM NO.</p>
--	--